



SEE THE LIGHT? WE CAN HELP.

Check it out. A TPMS system check is as easy as getting into your car and turning your ignition on. If your TPMS indicator light turns off, you're on your way. If it remains on or flashes, you may have an issue:



FLASHING TPMS LIGHT

You have a system failure and more than likely a bad sensor. Have a service professional check it out.



SOLID TPMS LIGHT

If your light stays on, check your tires for proper inflation or damage.

Standard® OE-Matching Direct-Fit TPMS Sensors need no programming so they're ready to install right out of the box. Ask your technician to check your TPMS every time your tires are serviced!



STANDARD® *OE-Match*
Intermotor®  **TPMS**
Genuine Import Parts **SENSORS**

StandardOEMatchTPMS.com

Ask about our
QWIK™
sensor
MULTI-COVERAGE
TPMS Sensors