

# « JUST THE FACTS »

## TPMS Sensor ID Number Locator

The TPMS Sensor ID can be located in various locations on the TPMS sensor and can be either numeric or alphanumeric. TPMS sensors using a numeric ID will consist of 0-9. TPMS sensors using a alphanumeric ID will consist of 0-9 and A-F. These 16 characters provide more than 2 trillion sensor ID combinations. So, a TPMS sensor ID will normally be 7-8 characters, but can be 10. The following are examples of sensor ID locations and are not all inclusive of every sensor.

**IMPORTANT:** After removing the sensor from the tire, use our TPMS Application and Illustrated Parts Guide STTPMS-13 to determine the appropriate sensor needed to replace the OE sensor. Determine the OE sensor identification number by reading the sensor or using a scan tool.



### Typical OE Sensor ID Number Location



**Schrader® Style Sensor**  
Chevy, Chrysler, Dodge, Ford, Infiniti, Isuzu, Jeep, Mitsubishi, Nissan, Saab, Saturn, Subaru, Suzuki



**Schrader® Style Sensor**  
Buick, Cadillac, Chevy, GMC, Hummer, Isuzu, Pontiac, Saturn



**Pacific Style Sensor**  
Acura, Honda, Infiniti, Lexus, Nissan, Pontiac, Scion, Toyota



**Siemens/Continental Style Sensor**  
Audi, Chrysler, Dodge, Hyundai, Jaguar, Jeep, Mitsubishi, Volkswagen



**Banded Sensor**  
Ford, Lincoln, Mercury, Mazda



**Continental Style Sensor**  
Chrysler, Honda, Hyundai, Jaguar, Kia, Land Rover, Mazda, Suzuki, Volvo, Volkswagen



**Snap-In Style Sensor**  
Buick, Cadillac, Chevy, Dodge, GMC, Ford, Jeep, Mercury, Mitsubishi, Pontiac, Saab, Subaru, Suzuki, Volvo



**Adjustable Angle Sensor**  
Mercedes-Benz